

# Port Mirroring Configuration Commands

## Table of Contents

Chapter 1 Configuring Port Mirroring Commands.....	1
1.1 Port Mirroring Configuration Commands .....	1
1.1.1 mirror .....	1
1.1.2 show mirror.....	1

# Chapter 1 Configuring Port Mirroring Commands

## 1.1 Port Mirroring Configuration Commands

The following are port mirroring configuration commands:

- mirror
- show mirror

### 1.1.1 mirror

#### Description

```
[no] mirror session session_number {destination {interface interface-id} | source {interface interface-id [, | -] [both | rx | tx ]}}
```

It is used to configure the command.

#### Parameters

Parameter	Description
session_number	Number of port mirroring, whose value is 1
destination	Information about the destination port mirroring
source	Information about the mirrored port
both / rx / tx	Data flow that will be mirrored  rx means that the input data is mirrored. tx means that the output data is mirrored. both means that input and output data are mirrored.

#### Instruction

Configure the command at the global configuration mode.

#### Example

Port g0/2 functions as the output mirror of port g0/1.

```
Switch(config)# mirror session 1 destination interface g0/2
Switch(config)# mirror session 1 source interface g0/1 tx
```

### 1.1.2 show mirror

#### Description

```
show mirror [session session_number]
```

It is used to display the port mirroring information.

**Parameter**

Parameter	Description
<i>session_number</i>	Number of port mirroring, whose value is 1

**Default**

None

**Instruction**

It is used to display the port mirroring information.

**Example**

All port mirroring information are displayed.

Switch# show mirror

Session 1

-----

Source Ports:

RX Only: Fe0/3

TX Only: None

Both: None

Source VLANs:

RX Only: None

TX Only: None

Both: None